

S212_nrf52_0.5.1_migration document

Contents

S212_nrf52_0.5.1 Migration	2
Required changes.....	2
License Key.....	2

S212_nrf52_0.5.1 Migration

This section describes how to migrate to the S212_nrf52_0.5.1 from S212_nrf52_0.3.0

Required changes

License Key

A new parameter added to the `sd_softdevice_enable()` call, `p_license_key`, is used to enable SoftDevices that include ANT. Without this parameter, the SoftDevice will not initialize and will be non-functional. For evaluation purposes, an evaluation key is provided in `nrf_sdm.h`. It is a requirement to obtain and use a commercial use license key with the S212 in any product that is sold or otherwise distributed for revenue-generating purposes. In order to use the evaluation key, two steps are required:

1. Open `nrf_sdm.h` and uncomment the `ANT_LICENSE_KEY` definition, as shown in the code snippet below:

```
/** @brief Evaluation key for the ANT SoftDevices. Use this key in sd_softdevice_enable call to start
    using the evaluation stacks. You MUST obtain a valid commercial license key BEFORE releasing a
    product to market that uses the ANT SoftDevices. For more information about licensing please
    visit the website below:
    https://www.thisisant.com/developer/ant/licensing */

// #define ANT_LICENSE_KEY "3831-521d-7df9-24d8-eff3-467b-225f-a00e" ← UNCOMMENT

#ifdef ANT_LICENSE_KEY
#error "You must obtain a valid license key to use ANT. You may use the evaluation key for non commercial
use only by uncommenting it above this error. Commercial use license keys are available from ANT
Wireless."
#endif
```

2. Modify all calls to `sd_softdevice_enable()` to add the license key as the third variable. The call should be changed as follows from this:

```
sd_softdevice_enable(1f_clock_source, softdevice_assert_callback);
```

to this:

```
sd_softdevice_enable(1f_clock_source, softdevice_assert_callback, ANT_LICENSE_KEY);
```